Infiltration Calculations



Average Annual Rainfall = 28.81 inches

Notes:

- 1.) Infiltration calculations are based on runoff volume outputs from WinSLAMM v10.2.1
- 2.) = Cells That Require Data Input.

Pre-Development Infiltration Calculations:

- 1.) Pre-development Project Site Area = 0.299 acres
 - 0.299 acres * (43,560 sq. ft./1 acre) = 13,024 sq. ft.
- 2.) Pre-development runoff volume = 1,985 cu. ft.
- 3.) Pre-development runoff depth = (1,985 cu. ft. / 13,024 sq. ft.)
 - = 0.15 ft.
 - = 1.83 in.
- 4.) Pre-development stay-on depth = (28.81 in. 1.83 in.)
 - = 26.98 in

Target Post-Development Stay-On Depth = 100% of Pre-Development Stay-On Depth

- 5.) Target Post-development stay-on = (26.98 in. * 1)
 - = 26.98 in.

Post-Development Infiltration Calculations:

- 1.) Post-development Project Site Area = 0.299 acres
 - 0.299 acres * (43,560 sq. ft./1 acre) = 13,024 sq. ft.
- 2.) Post-development runoff volume = 4,726 cu. ft. (Only one year of modeling MAD 1981)
- 3.) Post-development runoff depth = (4,726 cu. ft. / 13,024 sq. ft.)
 - = 0.36 ft.
 - = 4.35 in.



Post-Development Infiltration Calculations (Continued):

- 4.) Post-development stay-on depth = (28.81 in. 4.35 in.)
 - = 24.46 in
- 5.) Post-development stay-on percentage as compared to pre-development stay-on:

The post-development project site infiltrates approximately 90.6% of the pre-development infiltration volume.

